


# Instructions for Multimedia Room 1

## You can use the following equipment:

- Desktop Computer
- VGA and HDMI hookup for laptop
- Blu-ray Player with remote
- Ladibug Document camera (using the Desktop Computer)

## Turn the projector on

- If the touch panel is dark, touch it to activate it.
- Press the **PROJECTOR POWER** button, followed by the **PROJECTOR ON** button.
- There will be a **30 second delay** as the projector warms up. The screen will automatically come down.



Touch Panel

## Select device on Touch Panel

- For the **desktop computer**, press **Internal PC**.
- For a **laptop with VGA connection**, plug the VGA and audio connectors into the laptop. Press the **LAPTOP VGA** button.
- For a **laptop with HDMI connection**, plug the HDMI cable into the laptop. Press the **LAPTOP HDMI** button.
- For the **Blu-ray Player**, press **Blu-ray DVD**. Use the control buttons on the touch panel or use the remote to access the DVD menu or move to different chapters.
- For the **Ladibug Document camera**, press **Internal PC**. Use the Ladibug software located on the desktop computer. Additional instructions are located on the podium.

Use the **Display Image ON/OFF** button if you want to keep the image ready but want the screen to be dark.

**Volume** is controlled through the touch panel. If you are using a laptop, please make sure the master volume on the laptop is high.

**Drapes** are controlled by the touch panel. **Lights** are controlled by the switch located next to the entrance door.

## Troubleshooting

### Video

#### • If your device is not projecting:

Try selecting a different device and then switch back.  
Try restarting your device.

#### • If your laptop is still not projecting :

Check your cable connections and make sure LAPTOP VGA or HDMI is selected on the touch panel. **For a PC**, hold the Windows key and letter P, and choose "duplicate." **For a Mac**, make sure your display setting is "mirroring."

### Audio

- **If you cannot hear any sound from HDMI:** you may have to change your audio output on your laptop. **For a PC**, right-click on the sound icon and choose "Playback devices". Then choose "Crestron". **For a Mac**, Option-Click on the sound icon. Then choose "Crestron" for your Output Device.

Please **CALL MEDIA SERVICES (504-864-7120)** for any assistance.

Please **press TURN SYSTEM OFF** at the end of your class!